SERVICE PROCEDURE
KN0414-KIT MOLDED FOOT KIT
MIDSIZE INSTALLATION

PURPOSE

This document outlines how to install the KN0414-KIT Molded Foot Kit – Midsize if it becomes damaged.

REQUIRED TOOLS:

- 5mm hex key
- Blue Loctite™ 242
- Adjustable torque wrench

1. Removed molded foot using 5mm hex key.

2. Install replacement molded foot and bolts. Apply blue Loctite™ and torque to 75in-lbs.

AMKUS RESCUE SYSTEMS
AMKUS.COM

4201 MONTDALE DRIVE, VALPARAISO, IN 46383-4098 USA
800-592-6587 · 219-548-5000

©Copyright AMKUS Rescue Systems 2024